



D660S, 2696Z0004: **A**
D770, 2696Z0001: **B**

D880, 2696Z0002: **C**
D880S, 2696Z0003: **D**

Description	Pos.	Part Nbr. Best.-Nr.	Quantity/ Stk.				Bezeichnung
			A	B	C	D	
Housing	1	4000226	1	-	-	-	Gehäuse
	1	1040016	-	1	-	-	
	1	1040017	-	-	1	-	
	1	1040018	-	-	-	1	
Grid cap	3	1030206	-	1	-	-	Gitterkappe
	3	1030006	1	-	-	-	
	3	1030205	-	-	1	1	
Foam insert	3.1	7030103	-	1	1	1	Schaumeinlage
Foam insert, front	3.1	7030086	1	-	-	-	Schaumeinlage, vorne
Foam insert, rear	3.2	7030016	1	-	-	-	Schaumeinlage, hinten
Capsule with suspension	5	2610Z0024	1	-	-	-	Kapsel mit Lagerung
	5	2610Z0022	-	1	-	-	
	5	2610Z0023	-	-	1	1	
Switch	6	1400E0001	1	-	-	1	Schalter
Switch label	7	1400S0001	1	-	-	1	Schalterschild
Slider	8	1400Z0601	1	-	-	1	Schieber
Screw for switch	9	4040053	2	-	-	2	Schraube für Schalter
XLR insert	10	5090035	1	1	1	1	XLR-Steckereinsatz
Screw for XLR	11	4040098	1	1	1	1	Schraube für XLR
Stand adapter	12	6001H0632	1	1	1	1	Stativanschluß
Carrying bag	--	1603P0001	1	1	1	1	Zipptasche

